


Pop Up Camper Cover Instructions

Accessories List

			
Pop Up Camper Cover x1	Reinforced straps x2	Front and end buckle straps x2	
			
Side buckle straps x3	Throwing bag x1	Jack cover x1	
			
Spare buckles x2	Adhesive repair patches x1	Storage bag x1	Installation instruction x1

Pre-Installation Checklist

- Accessories Classification: Remove all contents from the box for inspection; if you find missing parts or accessories, please contact us via Amazon!
- Please make sure the RV is clean and dry before installing the RV cover.
- Please check the RV for any sharp edges that may puncture the RV cover.

Safety and Maintenance



- When installing the RV cover, please retract the awning.
- Two people are safer and more convenient to operate during installation and removal.
- Avoid installation on windy days or when the roof is slippery.
- When raising the RV cover, please avoid obstructing it with sharp objects.

Installation Guide




1. Put the jack cover over the jack and tighten the rope.






2. Identify the front of the cover – (pic.1) Locate the white label on the cover that says "Front." Roll up the cover, from back to front, and place it on the trailer. (pic.2)






3. When the RV cover is spread out, fold 1/3 over the top (pic.3), then the other 1/3 over the top (pic.4). Loosely roll up the RV cover from the BACK to the FRONT. (pic.5)




4. Sweep the RV roof for debris before installation. (pic.6) Position the rolled-up cover on the front of the RV roof. (pic.7) Unroll the RV cover on the roof from front to back, Ensure the FRONT and BACK tags are on the corresponding sides of the RV. (pic.8)






5.Unfold the RV cover completely, drop down the RV cover and distribute the cover evenly. (pic.9/10/11)






6. Attach the front and back straps then pull them tight. (pic.12) DO NOT over-tighten the straps.



10.Take one end of the side straps and buckle it to the sewn buckle on the triangle piece on one side of the cover, connect the binding to the throwing bag (Pic. 13), and throw the straps underneath the RV to the other side. (Pic. 14) Unfasten the throwing bag, fasten it to the other side of the triangle piece sewing buckle, and pull it tight. (Pic. 15) repeat the above steps for the other triangle piece buckles to secure the side straps.




11.Throw the long reinforced strap over the camper (do not use it with the throwing bag). After placing the long strap on the other side, attach the throwing bag and throw it back under the camper on the other side (Pic. 17). Disconnect the throwing bag and close the loop. (Pic. 18) Tighten the strap position. Repeat for the other long strap.




12. In the end, connect the longest strap across the ribbon loop of the RV cover and secure it.

Installation complete.



13.The package includes an RV cover repair patch for temporary repairs. You may cut off the repair patch, and attach them on both the inside and outside of the torn part comparatively. If the repair patch is insufficient, please contact us.



Clean and Care

- 1.We suggest using a sponge with a mixture of detergent and water when cleaning your RV cover.
2. DO NOT machine wash the RV cover, or it might render the UV-resistance property useless.
3. DO NOT use a brush or complex objects to clean the cover.
4. Please ensure the RV cover is dry when folding it up for storage.

How to Remove Your RV Cover

To remove your RV cover, simply reverse the how-to-install process above and return the cover back to the storage bag. To easily fit your cover in the storage bag, fold and roll it tightly rather than stuffing it.

Important: Do NOT store a wet cover in the storage bag or confined area as the cover can be damaged by mildew.